




## MODEL 132L PLANETARY GEAR DRIVE SERVICE MANUAL



**WARNING:** While working on this equipment, use safe lifting procedures, wear adequate clothing and wear hearing, eye and respiratory protection.

THIS SERVICE MANUAL IS EFFECTIVE:  
S/N: 48501 TO CURRENT  
DATE: 8/31/00 TO CURRENT  
VERSION: SM132LD2-AD

**NOTE:** Individual customer specifications (mounting case, output shaft, brake assembly, etc.) may vary from exploded drawing and standard part numbers shown. If applicable, refer to customer drawing for details.




X132LD2-AE,

Page 1 of 2

Effective date 8/31/00

Effective serial # 48502

E.C.N. 2790

EQUIPPED WITH PATENTED "LOAD-N-LOCK"  SHAFT RETENTION SYSTEM.  
(U.S. PATENT NO. 5746517).

X132LD2-AE DATE 11-19-07

ITEM	QTY	DESCRIPTION	SINGLE PLANETARY		DOUBLE PLANETARY							
			4:1 4.42	6:1 6.00	19.54:1 4.42 4.42	26.52:1 4.42 6.00	33.00:1 7.50 4.42	36.00:1 6.00 6.00	36.00:1 6.00 6.00	45.00:1 7.50 6.00		
BASE	1	1	MODEL 132L		RATIOS							
			DESCRIPTION									
			A - ROUND FLANGE		13-004-3102							
			A - ROUND FLANGE W/BOOT SEAT		13-004-3042							
			B - SQUARE FLANGE		13-004-3082							
			E - RECTANGULAR		13-004-3052							
			F - FLANGELESS		13-004-3152							
OUTPUT SHAFT	2	1	AQ - ECCENTRIC, ROUND FLANGE		13-004-3112							
			C - CUSTOM									
			D1 23 T 8/16 DP SPL 2.25" LG		13-004-4352M							
			D2 3.000" DIA, 5/8" SQ KEY		13-004-4312M							
			D3 23 T 8/16 DP SPL 1.22" LG		13-004-4362M							
			D4 23 T 8/16 DP SPL 2.72" LG		13-004-4372M							
			D5 3.500" DIA, 7/8" SQ KEY		13-004-4382M							
COVER	3	1	D6 20T 6/12 DP SPL 4.15" LG		13-004-4342M							
			S1 SPINDLE SHAFT		13-004-4202M							
			C1 CUSTOM									
			SAE 'A' 2 & MOD. 4 BOLT				13-004-1192	13-004-1192	13-004-1222		13-004-1192	13-004-1222
			SAE 'A' 2 & MOD. 4 BOLT W/ CODE 4		13-004-1252		13-004-1252	13-004-1252	13-004-1222	13-004-1222		13-004-1222
			SAE 'B' 2 BOLT				13-004-1182	13-004-1182	13-004-1232		13-004-1182	13-004-1232
			SAE 'B' 2 & 4 BOLT W/ CODE 4		13-004-1202		13-004-1202	13-004-1202	13-004-1232	13-004-1232		13-004-1232
INPUT GEAR	4	1	SAE 'C' 2 BOLT & 4 BOLT		13-004-1212		13-004-1212	13-004-1212	13-004-1242	13-004-1242	13-004-1212	13-004-1242
			SAE 'D' 4 BOLT W/ CODE 9 **		13-004-1412							
			CODE 2 - INPUT 13 T 16/32 DP				13-004-1292	13-004-1292	13-004-1312		13-004-1302	13-004-1312
			CODE 3 - INPUT SAE 1"-6B				13-004-1322	13-004-1322	13-004-1472		13-004-1332	13-004-1472
			CODE 4 - INPUT 14 T 12/24 DP		13-004-1372	13-004-1382	13-004-1342	13-004-1342	13-004-1362	13-004-1352		13-004-1362
			CODE 5 - INPUT 15 T 16/32 DP				13-004-1452	13-004-1452	13-004-1802		13-004-1442	13-004-1802
			CODE 9 - INPUT 13 T 8/16 DP **		13-004-1402	13-004-1462						
5	(1)	CARRIER ASSEMBLY-SECONDARY	13-005-2001	13-005-2011	13-005-2001	13-005-2011	13-005-2001	13-005-2011	13-005-2011	13-005-2011	13-005-2011	
		5A 1 CARRIER (SEC)	13-004-1062	13-004-1072	13-004-1062	13-004-1072	13-004-1062	13-004-1072	13-004-1072	13-004-1072	13-004-1072	
		5B 3 PLANET GEAR (SEC)	13-004-1082	13-004-1092	13-004-1082	13-004-1092	13-004-1082	13-004-1092	13-004-1092	13-004-1092	13-004-1092	
		5C 3 PLANET SHAFT (SEC)	81-004-0061									
		5D 6 BRG - SEC. PL.	01-105-0500									
		5E 6 THRUST WASHER - PLANET	81-004-1561									
		5F 3 ROLL PIN - SEC. PL. 3/16 X 7/8	01-153-0210									
		6 1 SUN GEAR			13-004-1142	13-004-1152	13-004-1142	13-004-1152	13-004-1152	13-004-1152	13-004-1152	
		7 (1) CARRIER ASSEMBLY-PRIMARY			13-005-2021	13-005-2021	13-005-2041	13-005-2031	13-005-2031	13-005-2031	13-005-2041	
		7A 1 CARRIER (PRI)			13-004-1032	13-004-1032	13-004-1052	13-004-1042	13-004-1042	13-004-1042	13-004-1052	
		7B 3 PLANET GEAR (PRI)			13-004-1102	13-004-1102	13-004-1122	13-004-1112	13-004-1112	13-004-1112	13-004-1122	
		7C 3 PLANET SHAFT (PRI)			13-004-1021							
		7D 3 BRG - PRI. PL.			01-105-0590							
		7E 6 THRUST WASHER - PLANET			81-004-1561							
		7F 3 ROLL PIN - PRI. PL. 1/8 X 7/8			01-153-0180							
		12 1 RING GEAR			81-004-2362							
14 -- THRUST WASHERS & THRUST BRGS												
14A 1 CARRIER THRUST WASHER			81-004-2711									
14B 1 CARRIER THRUST WASHER			81-004-2711			81-004-2711	81-004-2711		81-004-2711	81-004-2711		
14C 1 INPUT THRUST WASHER			81-004-2883		81-004-2701	81-004-2701			81-004-2701			
14D 1 THRUST WASHER SGL PL			01-112-0030									
14E 1 BEARING							01-112-0220	01-112-0220		01-112-0220		
14F 2 THRUST RACE							01-112-0230	01-112-0230		01-112-0230		
16 (1) SEAL KIT			13-016-2051 Contains Items 16A, 16B and 16C: 13-016-2101 SEAL KIT contains only items 16A and 16B									
16A 1 SHAFT SEAL			01-405-0690									
16B 2 O-RING			01-402-0420									
16C 1 SEAL - RUBBER (DIRT BOOT)			01-406-0050 DIRT BOOT IS USED ON THE S1 SPINDLE SHAFT WITH A 13-004-3042 OR 13-004-3052 BASE.									
20 --- OUTPUT SHAFT BEARINGS												
20A 1 OUTER CONE			01-102-0260									
20B 1 OUTER CUP			01-103-0260									
20C 1 INNER CONE			01-102-0030									
20D 1 INNER CUP			01-103-0030									
25 --- HARDWARE												
25A 8 BOLTS - COVER			01-150-1670		(FOR 13-004-1402 COVER, USE 01-150-1710 SHCS)							
25B 8 LOCKWASHERS - COVER			01-166-0010		(FOR 13-004-1402 COVER, DO NOT USE LOCKWASHERS)							
25C 16 BOLTS - RING			01-150-1460									
25D 16 HARD WASHERS - RING			01-166-0120									
30 --- PLUGS /GREASE ZERK												
30A 1 PLUG - COVER			01-207-0070									
30B 2 PLUG - RING			01-207-0041									
30C 1 1/4 NPT (SOC. HD.)			01-207-0020									
GREASE FITTING			01-215-0040									
35 --- MISCELLANEOUS												
35A * SHIMS			80-004-1151 ( * QUANTITY DETERMINED BY PRELOAD REQUIRED AND PART STACK-UP)									
35B 1 SPLIT RING			81-004-8101									
35C 1 LOCK RING			81-004-8111									
35D 1 RETAINING RING			01-160-0040									


ive serial # 48502

\*\* SAE "D" COVER IS SOLD ONLY WITH A CODE 9, 13 T- 8/16 INPUT GEAR.

## LUBRICATION & MAINTENANCE

Using the chart below, determine an appropriate lubricant viscosity. Use only EP (extreme pressure) or API GL-5 designated lubricants. Change the lubricant after the first 50 hours of operation and at 500 hour intervals thereafter. The gear drive should be partially disassembled to inspect gears and bearings at 1000 hour intervals.







### Recommended ambient and operating temperatures for conventional and synthetic gear lubricants



**Note:** Ambient temperature is the air temperature measured in the immediate vicinity of the gearbox. A Gearbox exposed to the direct rays of the sun or other radiant heat sources will operate at higher temperatures and therefore must be given special consideration. The max operating temp must not be exceeded under any circumstances, regardless of ambient temperature.

If your unit was specified "shaft up" or with a "-Z" option, a grease zerk was provided in the base housing. For shaft-up operation, the output bearing will not run in oil and must be grease lubricated. Use a lithium based or general purpose bearing grease sparingly every 50 operating hours or at regular maintenance intervals. Over-greasing the output bearing should be avoided as it tends to fill the housing with grease and thicken the oil

## ESKRIDGE MODEL 132L OIL CAPACITIES

Operating Position		Oil Capacity	Oil Level	
		Single/Double stage		
	Horizontal Shaft	3.0 pints / 1.4 l	To horizontal centerline of gear drive	
	Vertical Shaft (Pinion Up)	5.0 pints / 2.4 l	To side port on ring gear	
	Vertical Shaft (Pinion Down)	5.0 pints / 2.4 l	To midway on upper/primary gear set	

## ESKRIDGE PART NUMBER INTERPRETATION

**Note:** All non custom Eskridge Geardrives are issued a descriptive part number which includes information regarding the Model, means of shaft retention, base style, shaft style, input mounting, input shaft size, overall ratio and various available options. For a detailed breakdown of this information, please refer to Eskridge product specification sheets found at: <http://www.eskridgeinc.com/geardrives/gearprodspecs.html>

The 132L is no longer sold for new applications and the part number description is not available on the web. Use the 130L information to aid in interpreting the part number. For new applications, consider the 133L which has a large shaft like the 132L and it has higher load-rated planet bearings which give a longer life in most applications.



# Unit Teardown

- 1) Scribe a diagonal line across the outside of the unit from the cover (3) to the base (1) before disassembly to aid in the proper positioning of pieces during reassembly.
- 2) Remove drain plugs (30B) and drain oil from unit. The oil will drain out more quickly and completely if warm.
- 3) Remove the 8 3/8-16 cap-screws (25A) and lockwashers (25B).
- 4) Remove the cover (3), thrust washer(s)/bearing(s) (14C or 14E & 14F OR 14B, 14C, 14D & 35D), and input gear (4). Inspect o-ring (16B); discard if damaged or deformed.
- 5) Lift the planet carrier assembly out of the unit .
- 6) Remove secondary carrier assemblie. Remove ring gear (12), if necessary by removing the 16 1/2-13 12-point cap-screws (25C & 25D). Inspect the gear to base O-ring (16B); as before, discard if damaged or deformed.
- 7) The unit is now disassembled into groups of parts. The area(s) requiring repair should be identified by thorough inspection of the individual components after they have been cleaned and dried.

## Carrier Assembly Teardown

Rotate planet gears (7B pri/5B sec) to check for abnormal noise or roughness in bearings (7D pri/5D sec). If further inspection or replacement is required, proceed as follows.

- 1) Drive roll pins (7F pri/5F sec) completely into the planet shafts (7C pri/5C sec).
- 2) Slide planet shafts (7C pri/5C sec) out of carrier (7A pri/5A sec).
- 3) Remove planet gears (7B pri/5B sec), washers (7E pri/5E sec) and bearings (7D pri/5D sec) from carrier (7A pri/5A sec).
- 4) Inspect the planet gear (7B pri/5B sec), bearing bore and planet shaft (7C pri/5C sec) and bearings (7D pri/5D sec). Check for spalling, bruising or other damage and replace components as necessary.
- 5) Remove roll pins (7F pri/5F sec) from planet shafts (7C pri/5C sec) using a 1/16 pri/ 3/16 sec inch pin punch.

## Carrier Reassembly

- 1) Insert the bearings (7D pri/5D sec) into the planet gears (7B pri/5B sec). Place a planet washer (7E pri/5E sec) on top and bottom of planet gear and slide into carrier (7A pri/5A sec).
- 2) Planet shafts (7C pri/5C sec) should be installed with chamfered end of 1/16 pri/3/16 sec inch roll pin hole towards out-side diameter of carrier (7A pri/5A sec); this will ease alignment of holes while inserting roll pins (7F pri/5F sec).
- 3) Drive roll pin (7F pri/5F sec) into the carrier hole and into planet shaft to retain parts. Repeat for remaining planet gears.

## Base Subassembly Teardown

- 1) Remove the lock ring (35C) using a heel bar or puller; if using a heel bar, be sure not to pry against the cage of the inner output shaft bearing (20C). Remove the split ring segments (35B) and shims (35A).

**Caution:** Since the shaft is no longer positively retained, care should be taken to avoid personal injury. Care should also be taken not to damage it while pressing through base.

**Note:** Removing the shaft from the base assembly damages the shaft seal and the seal will need to be replaced.

- 2) Place base (1) external side down, on a plate or table. Press output shaft out bottom of base by applying a load to internal end of shaft until it passes through inner shaft bearing cone (20C).
- 3) A gear puller may be used to remove the outer bearing cone (20A) from the shaft (2). If reusing old bearing cone, do not pull on or damage roller cage. Remove the shaft seal (16A) for replacement.
- 4) Lubricate inner lip of new shaft seal (16A) and slide it onto the shaft (2) until it fits snugly over the shaft seal diameter with the open side toward the inside of the gear drive.

**Note:** Press bearing cone onto output shaft by pressing on inner race only. DO NOT press on roller cage, as it may damage bearing.

- 5) Inspect inner and outer bearing cups (20D & 20B). If cups are damaged, drive them out using a brass drift and utilizing the bearing knock-out notches in the base (1)

## Base Reassembly

- 1) Clean all foreign material from any magnetic oil plugs located on base (1).
- 2) Place base (1) exterior side up on work table.
- 3) Apply a layer of lithium or general purpose bearing grease to the roller contact surface of outer bearing cup (20B).
- 4) Press outer bearing cone (20A) onto the shaft until it seats against the shoulder.
- 5) Place the shaft (2) with the bearing (20A) into the base (1).
- 6) Flip shaft/base assembly, and apply lithium or general purpose bearing grease to roller contact surface of the inner cup (20D)., then press inner bearing cone (20C) onto shaft (2) until it seats against inner bearing cup (20D).
- 7) Prior to installation of the shaft seal (16A), the pre-load may result in a rolling torque which varies between 50 to 350 in-lb. The bearing pre-load should be tailored to your application; a low-speed application may require a high pre-load, while high-speed applications usually benefit from low pre-load. Adding shims (35A) will increase the pre-load on the bearing set. Determine your pre-load requirement and install shims to obtain this pre-

load.

Install the Load-N-Lock™ segments (35B) over the shims (35A) and into the groove in the shaft (2). Finally, install the lock ring (35C) over the segments (35B).

All subassembly service or repairs should be complete at this time. Continue to Unit Assembly to complete unit buildup..

## Unit Assembly

- 1) Install the secondary carrier assembly (5) onto the output shaft; align the splines of the carrier (5A) with the output shaft (2) splines and slide the carrier onto the shaft.
- 2) Lubricate o-ring(s) (16B) and install on the base (1) pilot and cover (3) pilot.

**Caution: Hold ring gear(s) by outside diameter or use lifting device to prevent injury.**

- 3) Align gear teeth of secondary ring gear (12) with the gear teeth of the planet gears (5B) and place on base., then align mounting holes of ring gear with holes in base. Use the scribed line made during disassembly for reference.
- 4) Install and torque the 16 1/2-13 12-point counter-sunk head cap-screws (25C) with hard washers (25B). The torque for the cap-screws: **110 ft-lb dry, 90 ft-lb** if the fasteners are lubricated.
- 5) Install the primary carrier assembly (7) and sun gear (6) into the secondary carrier.
- 6) Install the input gear (4).
- 7) Install the thrust bearing set (**Either 14C or 14E & 14F or 14B, 14C, 14D & 35D**) Refer to exploded view for details.
- 8) Noting the scribed line made during disassembly, (with lubricated o-ring in place) align and install the cover (3). Install the 8 3/8-16 hex-head cap-screws and lockwashers (**25A and 25B**). Tighten to a torque of **45 ft-lb dry, 35 ft-lb** if the fasteners are lubricated.
- 9) Using a splined shaft to drive the input gear (4) ensure that the unit spins freely.
- 10) Fill the unit to the proper level, as specified, with recommended gear oil (refer to chart, page 3) after unit is sealed with brake and/or motor.

**The gearbox is now ready to use.**